

NanoEdge AI Studio to STM32CubeIDE app that  
receives Anomaly Detection input via COM Port

No Physical Sensors Required  
Presenter Stephen MacKenzie

# Resources

- Download NanoEdge AI Studio:
  - <https://stm32ai.st.com/download-nanoedgeai/>
- ST Electronics NanoEdge AI Studio docs and tutorials:
  - <https://wiki.st.com/stm32mcu/wiki/Category:NanoEdgeAI>
- Anomaly Detection YouTube from ST:
  - [https://www.youtube.com/watch?v=yXMUv\\_C5FGk](https://www.youtube.com/watch?v=yXMUv_C5FGk)
- My GibHub (links to the project(s), see last slide)
  - <https://github.com/stevemac321>

# Overview – The Goal

- Build and demonstrate a functional anomaly detection pipeline with:
  - No physical sensor input
  - Simple pattern signal files, spaces and comma delim.
  - An STM32 board with ST-Link over USB
  - Core logic spanning NanoEdge AI Studio → Embedded App → COM port client

# GitHub Project Structure

- anomaly\_spaces\_for\_nanoedge.csv, regular\_spaces\_for\_nanoedge.csv for NanoEdge AI Studio signal input.
  - Anomaly.csv 5x140, regular.csv 20x140 for client-controller runtime.
- Embedded STM32CubeIDE project
  - USB STLink on COM Port
  - USART enabled, interrupt enabled
- NanoEdge AI Studio benchmarked algorithm, lib and header
  - Already “deployed” into Core/Inc and Core/lib into the STMCubeIDE project
- Python clients, console and option QT PySide6.

# Recommended WorkFlow for Portability

- Clone the NanoEdge\_Anomaly\_Detection project from:
  - [https://github.com/stevemac321/NanoEdgeAI\\_Anomaly\\_Detection](https://github.com/stevemac321/NanoEdgeAI_Anomaly_Detection)
  - This gives you access to main.c and stm32xxxx\_it interrupt code
  - Signal files, you skip the NanoEdge AI Studio if you want and just get the header and lib from Core/Inc and Core/Lib
- Create New STM32CubeIDE project for your board (unless you have a NUCLEO-H723ZG)
  - Enable USART (I use usart3 or whatever shares STLK\_VCP\_RX/TX)
  - Make sure baud rate matches your STLink COM port Enable interrupts, on windows open Device Manager (see readme for Linux)

# NanoEdge AI Studio — Creating the Anomaly Detection Model

- 
- New Project → Anomaly Detection
- Import signals
  - regular\_spaces\_for\_nanoedge.csv
  - anomaly\_spaces\_for\_nanoedge.csv
- Run Benchmark to evaluate candidate models
- Validation tab to choose best lib
- Deploy, creates emulator, lib, and header(s)

# Deploying the zipfile to the STMCube32IDE app

- Create STM32CubeIDE app for your board
- STM32CubeIDE app
- Extract zip
  - Copy NanoEdgeAI.h to STMCubeIDE Project: Core/Inc
  - Copy libneai.a to Core/lib
- Add libpath to Core/lib in project properties:
  - C/C++ General → Library Paths (add /<projectdirectory>/Core/lib)
  - C/C++ General → Libraries (add neai, not libneai and no file extension .a)

# Adding Training and Detection Code to the STM32CubeIDE embedded app

- You can just copy the cloned main.c into your project or these steps:
- In USER CODE BEGIN Includes section of main.c
  - Include headers: NanoEdgeAI.h, string.h (for memcpy), optional stdio.h for printf (you will need a `_write` function, its in the cloned main.c.
- In USER CODE BEGIN PM, `#define DATA_INPUT_USER 140`
- In USER CODE BEGIN PV:
  - `static float EKG_Input[DATA_INPUT_USER];` // pass to model
  - `static uint8_t rx_chunk[4];` // Temporary buffer to hold 4 bytes of one float
  - `static uint16_t ekg_index = 0;` // Index into EKG\_Input
  - `extern float training_data[][DATA_INPUT_USER];`
  - `extern size_t training_data_len;`
  -



# Adding Code in main.c (continued)

- In USER CODE BEGIN PFP add:
  - enum neai\_state train\_model();
- In USER CODE BEGIN WHILE add: (see cloned main.c)
  - if (train\_model() != NEAI\_MINIMAL\_RECOMMENDED\_LEARNING\_DONE) {
  - HAL\_UART\_Abort\_IT(&huart3);
  - \_\_HAL\_UART\_DISABLE\_IT(&huart3, UART\_IT\_RXNE);
  - } else {
  - // Start UART receive in interrupt mode
  - // Request the next 4 bytes (one float)
  - HAL\_StatusTypeDef hal\_ret = HAL\_UART\_Receive\_IT(&huart3, rx\_chunk, sizeof(rx\_chunk));
  - 
  - if(hal\_ret != HAL\_OK) {
    - //printf("receiveIT failed %d", hal\_ret);
    - return 0;
  - }
  - }

# Adding Code in main.c (more continued)

- In USER CODE BEGIN PFP add:
  - `enum neai_state train_model();`
- In USER CODE BEGIN WHILE add: the code cloned main.c that calls `train_model`
- In USER CODE BEGIN 4 (or whatever), add implementations:
  - `_write` (optional if you want `printf`)
  - `RxCpltCallback`
  - `train_model`

# Adding Interrupt Code

- Open the cloned Core/Src/stm32h7xx\_it.c file, find:
  - USART3\_IRQHandler
    - Make sure that HAL\_UART\_IRQHandler is called in your generated stm32xxxx\_it.c file.
  - Add this the code in USER CODE BEGIN USART3\_IRQn 1:
    - HAL\_UART\_RxCpltCallback into your stm32xxxx\_it.c file.

# Build, Debug

- Build the STM32CubeIDE project
- Debug (will flash your board)
- Once it is flashed, it will run, debugging is optional
- To send the board data, on your host run: `python EKG_Simulator.py`
- If you want to debug, set a breakpoint in `HAL_UART_RxCpltCallback`, inspect:
  - Status (see `NanoEdgeAI.h` for enum values)
  - Similarity (100 is “most regular”, 0 is “most anomaly”)
  - `EKG_Input` is the float array buffer from `uint8_t rx_chunk` from `HAL_UART_Receive_IT`, check `rx_chunk` too.

# EKG\_Simulator Results

- Return bytes
- Neai status
- Similarity (100 normal, 0 anomaly)
- There are just two samples hardcoded
- There is another project you can clone for a bit more variety:
  - [https://github.com/stevemac321/NanoEdge\\_Client](https://github.com/stevemac321/NanoEdge_Client)
  - This is a QT PySide6 app (see the readme in that project)

# Links

- This project enlistment:
  - [https://github.com/stevemac321/NanoEdgeAI\\_Anomaly\\_Detection](https://github.com/stevemac321/NanoEdgeAI_Anomaly_Detection)
- QT PySide6 Client enlistment:
  - [https://github.com/stevemac321/NanoEdge\\_Client](https://github.com/stevemac321/NanoEdge_Client)
- About Me:
  - <https://www.linkedin.com/in/stevemac321/>
- My Music and Technology YouTube Channel:
  - <https://www.youtube.com/@stephenmackenzie6782>